

INSTRUCTIONS FOR PROPER HEATING ELEMENT INSTALLATION

1. TURN OFF POWER TO DRYER.
2. Before disconnecting old heater, note its wiring for reconnection.
3. Check all wires and terminals. If necessary, replace them.
4. Carefully attach wire terminal to heater. DO NOT TWIST OR BEND HEATER CONNECTION AREA.
5. STRAIGHT FINSTRIP HEATERS NEED ROOM TO EXPAND. Mounting ends of these heaters should be set loose on screws.

For HEATERS, WIRE, WIRE TERMINALS, INFRARED PANELS & more

CALL TOLL-FREE: 800.444.PART



A Division of The A.W.T. World Trade Group
4321 N. Knox Ave., Chicago IL 60641 USA
773.725.4900 • Fax: 773.777.0909

REPLACEMENT PARTS AND REMANUFACTURING SERVICES FOR SCREEN PRINTING EQUIPMENT

parts@gpiparts.com • www.gpiparts.com